

Spring-2 installation on SBB-4



1. Disassemble Spring Back Bracket according to instructions in the SBB-4 package and follow the instructions to attach the bottom bracket to the boat surface. Attach the Armor Plate to the top bracket.
2. Hold the top and bottom brackets together and sit main spring in place. Push axle rod through spring from the left and axle assembling tool through the spring from the right side. This will keep the top and bottom bracket together. Now you can place Spring-2 onto the axle rod on the left. Hold the spring in place and push the tool through spring and forward until the assembling tool meets the axle. Thread into the axle rod. .
3. Once the tool is threaded into the axle rod pull the axle from the left to the right and out of the Spring Back Bracket.
4. Unthread the axle tool, place the Hex Head screw into the axle and tighten the screw securely.

NOTE: The pictures shown above are visual aids to assemble the axle and springs. When you are assembling the axle and springs, the bottom bracket should already be attached to your boat surface, as mentioned in line 1 above.

www.transducershieldandsaver.com